



Climate Master

decentralized
air conditioning systems



ROOM CABINET INSTRUCTIONS

NOTE: The room cabinet is shipped fully assembled and ready for installation. No dis-assembly and re-assembly is required. The cabinet should be installed only after the interior walls and the floors have been finished.

- Step 1. Remove front panel by lifting from center of bottom front edge.
- Step 2. Loosen (do not remove) screws that secure kick plate to the cabinet sides.
- Step 3. Position room cabinet over top of wall box mounting flange and set the two slots in the cabinet mounting angle on the threaded studs in the mounting flange. Push cabinet hard against wall until tape on back side of cabinet is compressed. Then tighten two wing nuts and lock washers over the threaded studs to fasten cabinet securely to the wall box mounting flange.
- Step 4. Adjust kick plate squarely on finished floor and re-tighten screws. Fasten kick plate securely to the finished floor using three (3) lag screws. (Holes provided in kick plate flanges.)

NOTE: Make sure tape on back side of cabinet is compressed equally on top and both sides for vibration free operation.

Step 5. If
be
mo
pa
mo
fi:

IOM 700RC 170

mediately, front panel may at this time. Set lower bottom of the cabinet side then lower it until upper part of cabinet. Press in place.

NOT

ion.

