




NOTES:

I. REFER BACK TO TABLES FOR CORRECT CXM, DXM OR DXM2 DIP SWITCH SETTINGS.


CXM 1 & 2 DIP SWITCH SETTINGS

SI		STD/ECON	LON	MPC
	1	ON	ON	ON
2	ON	ON	ON	ON
3	ON	ON	ON	ON
4	ON		OFF	OFF
5	ON	ON	ON	ON

SEE NOTE I.
CXM BOARD DIP SWITCH SETTINGS



SEE NOTE I.
DXM BOARD DIP SWITCH SETTINGS



DXM1 DIP SWITCH SETTINGS

SI		STD/ECON	LON	MPC	REHEAT	LON+REHEAT	MPC+REHEAT
	1	ON	ON	ON	OFF	OFF	OFF
2	ON	ON	ON	ON	ON	ON	
3	ON	ON	ON	ON	ON	ON	
4	ON	ON	ON	ON	ON	ON	
5	ON	ON	ON	ON	ON	ON	
6	ON	ON	OFF	ON	ON	OFF	
7	ON	ON	ON	ON	ON	ON	
8	ON	ON	ON	ON	ON	ON	

S2		STD/ECON	LON	MPC	REHEAT	LON+REHEAT	MPC+REHEAT
	1	ON	ON	ON	OFF	OFF	OFF
2	OFF	OFF	OFF	ON	ON	ON	
3	ON	ON	ON	OFF	OFF	OFF	
4	ON	ON	ON	ON	ON	ON	
5	ON	ON	ON	ON	ON	ON	
6	ON	ON	ON	ON	ON	ON	
7	ON	ON	ON	ON	ON	ON	
8	ON	ON	ON	ON	ON	ON	

DXM2 DIP SWITCH SETTINGS

SI		STD/ECON	LON	MPC	REHEAT	LON+REHEAT	MPC+REHEAT
	1	ON	ON	ON	OFF	OFF	OFF
2	OFF	OFF	OFF	ON	ON	ON	
3	ON	ON	ON	ON	ON	ON	
4	ON	ON	ON	ON	ON	ON	
5	ON	ON	ON	ON	ON	ON	
6	ON	ON	ON	ON	ON	OFF	
7	ON	ON	ON	ON	ON	ON	
8	ON	ON	ON	ON	ON	ON	

S2		STD/ECON	LON	MPC	REHEAT	LON+REHEAT	MPC+REHEAT
	1	ON	ON	ON	OFF	OFF	OFF
2	ON	ON	ON	ON	ON	ON	
3	ON	ON	ON	OFF	ON	OFF	
4	ON	ON	ON	ON	ON	ON	
5	ON	ON	ON	ON	ON	ON	
6	ON	ON	ON	ON	ON	ON	
7	ON	ON	ON	ON	ON	ON	
8	ON	ON	ON	ON	ON	ON	